



# Hendrickson Trailer Maintenance Schedule

Service Interval	Ride Height	Shock Absorber	Air Spring	Height Control Va	Frame Hanger	Tri-functional Bush / Pivot Connection	S-Cam	Slack Adjuster	Disc Brakes 4	Drum Brakes 1	Wheel Ends 2
<b>Predelivery</b>	I	I	I	I	I	I/C	L	L/A	I/C	I	
<b>30 Days</b>	I	I	I	I	I	I	L	L/A	I	I	I
<b>1st Quarter</b>	I	I	I	I	I	I	L	L/A	I	I	
<b>2nd Quarter</b>	I	I	I	I	I	I	L	L/A	I	I	I
<b>3rd Quarter</b>	I	I	I	I	I	I	L	L/A	I	I	
<b>4th Quarter</b>	I	I	I	I	I	I	L	L/A	I/R	I/R	I
<b>Year 1</b>											
<b>1st Quarter</b>	I	I/C	I	I/C	I	I/C	L	L/A	I	I	
<b>2nd Quarter</b>		I/R	I	I	I	I	L	L/A	I	I	I
<b>3rd Quarter</b>	I	I	I	I	I	I	L	L/A	I	I	
<b>4th Quarter</b>	I	I	I	I	I	I	L	L/A	I/R	I/R	I
<b>Year 2</b>											
<b>1st Quarter</b>	I	I/C	I	I/C	I	I/C	L	L/A	I	I	
<b>2nd Quarter</b>		I	I	I	I	I	L	L/A	I	I	I
<b>3rd Quarter</b>	I	I/R	I	I	I	I	L	L/A	I	I	
<b>4th Quarter</b>		I	I	I	I	I	L	L/A	I/R	I/R	I
<b>Year 3</b>											
<b>1st Quarter</b>	I	I/C	I	I/C	I	I/C	L	L/A	I	I	
<b>2nd Quarter</b>		I	I	I	I	I	L	L/A	I	I	I
<b>3rd Quarter</b>	I	I	I	I	I	I	L	L/A	I	I	
<b>4th Quarter</b>		I/R	I	I	I	I	L	L/A	I/R	I/R	I
<b>Year 4</b>											
<b>1st Quarter</b>	I	I/C	I	I/C	I	I/C	L	L/A	I	I	
<b>2nd Quarter</b>		I	I	I	I	I	L	L/A	I	I	I
<b>3rd Quarter</b>	I	I	I	I	I	I	L	L/A	I	I	
<b>4th Quarter</b>		I	I	I	I	I	L	L/A	I/R	I/R	I
<b>Year 5</b>											
<b>1st Quarter</b>	I	I/R	I	I/R	I	I/C	L	L/A	I	I	
<b>2nd Quarter</b>		I	I	I	I	I	L	L/A	I	I	I
<b>3rd Quarter</b>	I	I	I	I	I	I	L	L/A	I	I	
<b>4th Quarter</b>		I	I	I	I	I	L	L/A	I/R	I/R	I

**NOTES:**

- 1/ Minimum allowable brake lining thickness - 6mm
- 2/ Maximum allowable end play: .001" - .005"
- 3/ Use Catrol APXT
- 4/ Minimum disc pad thickness = 11mm  
(9mm back plate / 2mm lining)  
Minimum rotor thickness = 37mm

Key	
I	Inspect
I/R	Inspect/Replace as Required
I/C	Inspect/Check Torques
L/A	Lubricate/ Check Adjustment
L	Lubricate <sup>3</sup>

Note: Maintenance intervals may vary depending on conditions. Refer to service literature for more information